

## ACCENTS IN DESIGN – Machine Model / Shank Size Lookup Chart by Sewing Machine Brand (Make)

### IMPORTANT

Please refer to your machine's user manual to set your machine up properly for free motion quilting.

Alpha 4005 **Low**

Atlas 526 **Low**

American Beauty **Low**

Babylock: Most are LOW shank – Exceptions noted below:

Cresendo, Destiny, Aria, Unity, Journey, Spirit and Ellageo – **High Shank**

Babylock BLQC “AKA JANE”, BLQCP, BL500A – Use **High Shank - CRF**

Bernina 500, 600, Most others **Low with Bernina shank adapter**

700, 800, 820, 830, 880 – **Low with Bernina shank adapter**

**Old Style Presser Foot Type use Bernina shank adapter – Use Low foot with adapter.**

Brother: Most are **LOW** shank – Exceptions are noted below:

Brother: ULT2001, ULT2002, ULT2003D, XE-VM5100, XV8500D, VE2200, VM6200, VQ2400, VQ3000, VM1500, -  
**HIGH Shank**

Brother PQ1300, PQ1500S – **High Shank CRF foot**

Brother Nouvelle 1500 – **High Shank CRF foot**

Capital **Low**

Consew **Low**

Domestic **Low**

Dressmaker **Low**

Elna: Most are **LOW** shank – Exceptions are noted below:

Elna 700 Series, 800 Series, Super 64B, 580, 680, 7100, 7300 Pro – **High Shank**

Elna 900 Expressive – **High Shank**

EnVision 9006 **High**

Elnita **Low**

EuroPro Shark **Low**

## ACCENTS IN DESIGN – Machine Model / Shank Size Lookup Chart by Sewing Machine Brand (Make)

Ever Sewn **Low**

Good Housekeeper **Low**

Handi Quilter – **Low shank** – HQ210

Handi Quilter – **High Shank** – HQ710 Stitch

Handi Quilter – **High Shank – CRF** – HQ510 Stitch

Hobbymatic **Low**

Homemaker **Low**

Husqvarna Mega Quilter **High Shank – MGQ foot**

Husqvarna Designer SE Series machines - **Low**

Husqvarna/Viking Sapphire 960 – **Low** **Note: See Viking listing for additional information on set-up for Sapphires, Rubies, Topazes, Diamonds, Epic and Opal 690** **Needle position may need to be adjusted for centering.**

Husqvarna Diamond Royale – **Low** **(needle position adjustment from 0.0 to 0.5mm – Auto Fabric Thickness Sensor will be enabled when setting this machine to “free-motion” setting.**

Jaguar **Low**

Janome/New Home: Most are **LOW** shank – Exceptions noted below:

XC500, XC552, XC656A, 5000MC, 6600MC, 6600P, MC10000, MC11000 Special Edition, MC11000, MC10001, MC12000, MC15000, MC9500, MC9700, MC5000, MC5700, 7700QCP MC8000, MC8100HF, 8200QC, MC8900QCP, MC9000, MC7700 Horizon, 9400MC, 9500MC, 9700MC, 9900MC, Skyline S3, S5, S7, S9, 300EMC, 350EMC - **High**

Janome 1600P, 1600P-DB, 1600-QC **High Shank CRF Foot**

JCPenney **Low**

Juki – Most are LOW – Exceptions are noted below:

Juki DDL-227, DDL-555, DDL-8700, TL-98E, TL-98P, TL-98QE, – **Use High Shank CRF foot**

Juki – TL-2000 Qi – TL-2010Qi, TL-2200QVP Mini - **High Shank CRF Foot**

Kenmore – Most are LOW – Exceptions noted below: **please double check these with our shank chart on the ruler foot page. Some models may need a Medium or High – measure your shank.**

1914 **High**

**Super High Needs Kenmore Presser Foot Adapter #P60666 – use Low foot with the adaptor.**

## ACCENTS IN DESIGN – Machine Model / Shank Size Lookup Chart by Sewing Machine Brand (Make)

Montgomery Ward **Low**

Morse **Low**

Necchi - Most are LOW shank – Exceptions noted below:

Lydia MKA, Super Nova, 515, 542, 544, 1950, 1958 **High**

Nelco **Low**

R series-- **High**

Omega **Low**

Pennecrest **Low**

Pfaff - Most are LOW – Exceptions noted below:

**\*\* Most of the Pfaff machines noted below have a sensormatic free motion or using the Spring Free motion setting: Please refer to your manual on how to set up your machine for free-motion quilting. Needle adjustment may be necessary. All set-up changes can be found in your Menu settings.**

Creative Sensation Pro, Creative Sensation, Creative Vision, Creative Performance, Creative 4.5, 4.0, 3.0, 2.0, Performance 5.0, Quilt Expression 4.2, 4.0, Expression 2.0, 3.0, 3.2, 3.5, Expression 150, 2027, 2144, 2170, Pfaff Ambition – **Medium**

Pfaff 1197, 1199 and 1200 series-- **High**

Pfaff 1200 Grand Quilter – **High Shank MGQ Foot**

Phoenix Automatic **Low**

Riccar **Low**

Sierra **Low**

Simplicity **Low**

Singer Most are **Low** – Exceptions are noted below:

Vintage Singer Machines: If your vintage Singer uses generic low shank feet – **Low**

Singer 31-15 – **High Shank SS** – Special order, you will need to contact us directly.

Singer models that are “slant” shank: **“Fine Line” Clarity will not fit on slant shanks**, but we are exploring the slant shank machines in 2017. **If you are interested in participating in our development of a slant shank foot, please email us.**

## ACCENTS IN DESIGN – Machine Model / Shank Size Lookup Chart by Sewing Machine Brand (Make)

290C, 301, 400, 401, 401A, 403, 409, 417, 500, 500A, 501, 503, 503A, 600-class, 900-class, 1000-class, 1200-class, 1411, 1425, 2000-class, 2001, 2005, 2010, 7000, 750/691, 900 series, 4600 series, 700-class, 4572, 6200 series (many variations of shank but usually slant), 9117, 9134, and most Slant-o-matics, Touch-n-Sews, TouchTronics, & Athenas

Sonata **Low**

Sterling Automatic **Low**

Universal **Low**

Viking 100, 600, 1000, or #1 series has special Viking shank. : **"Fine Line" Clarity will not fit on this special Viking shank.**

140, 160, 1919, 200, 300, 400, 500, 550, 6000-series, 6000, 6020, 6170, 6230, 6270, 6360, 6370, 6430, 6440, 6460, 6680, 6690 & 8910 **Low**

Viking Opal 670 – **"Fine Line" Clarity foot does not fit this machine. This model does not have the Exclusive Sensor System for free-motion quilting.**

Viking Rubies, Epic, Diamonds, Topazes, Sapphires and the Opal 690 – **Low** - **Refer to your user manual for the proper set up for free motion quilting.**

900-series Slant – **"Fine Line" Clarity will not fit on slant shank machines.**

Vigorelli Most **Low**

White Most are **Low** – Exceptions noted below

White 628, 844, 1099, 1315, 2836 **High**

Wizard Most **Low**

Yamata **Low**